Wireless Device

SM-G313H

SERVICE Manual

Wireless Device



CONTENTS

1. Safety Precautions
2. Specification
3. Product Function
4. Exploded View and Parts list
5. MAIN Electrical Parts List
6. Level 1 Repair
7. Level 2 Repair
8. Level 3 Repair
9. Reference data

Notice: All functionality, features, specifications, and other product information provided in this document, including but not limited to, benefits, design, pricing, components, performance, availability, and capabiliti -es of the product are subject to change without notice. Samsung reserves the right to alter this doc -ument or the product described herein at anytime, without obligation to provide notification of such changes.

SAMSUNG
ELECTRONICS

This Service Manual is a property of Samsung Electronics Co.,Ltd.
Any unauthorized use of Manual can be punished under applicable
International and/or domestic law.

© Samsung Electronics Co.,Ltd.

2014. 06. Rev.1.0